

# Coraid® EtherDrive® HBA for Windows Server

## *Administration Guide*



Release date:  
21 November, 2011  
Rev D

© 2011 Coraid, Inc.

Except as specifically permitted herein, no portion of this document may be reproduced in any form or by any means without the express written consent of Coraid, Inc.

The trademarks, logos, and service marks (collectively "Trademarks") appearing on the Coraid website are the property of Coraid and other parties. ALL OF THE TRADEMARKS MENTIONED IN THIS MANUAL ARE THE PROPERTY OF THEIR RESPECTIVE OWNERS. Nothing contained in this document should be construed as granting any license or right to use any Trademark without the prior written permission of the party that owns the Trademark. Coraid and EtherDrive are registered trademarks of Coraid. Coraid trademarks include RAIDShield and VirtualStorage. Mac OS® is a registered trademark of Apple Inc. Microsoft, Encarta, MSN, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. OpenSolaris is a trademark of Sun Microsystems, Inc. or its subsidiaries in the U.S. and other countries. PCIe is a registered trademark of PCI-SIG. The term "Linux" is a registered trademark of Linus Torvalds.

Coraid, Incorporated  
255 Shoreline Drive, Suite 650  
Redwood City, California, 94065  
United States of America

---

Phone: +1-650-517-9300  
+1-877-548-7200

---

Fax: 1-650-226-3788

---

Web: <http://www.coraid.com>

---

Email: [support@coraid.com](mailto:support@coraid.com)

---

## Introduction

Thank you for purchasing a Coraid® EtherDrive® Host Bus Adapter (HBA).

The EtherDrive HBA and HBA software driver deliver ATA-over-Ethernet (AoE) technology to your Windows host for fast and affordable Ethernet SAN performance.

This guide explains how to install and configure your EtherDrive HBA to work inside a Windows host that is running any of the following operating systems:

- Microsoft Windows Server 2008 R2 64-bit (standard and Server Core installations)
- Microsoft Windows Server 2003 R2, 32- and 64-bit
- Microsoft Windows Server 2003, 32- and 64-bit

The EtherDrive SAN is comprised of one or more LUNs providing shared storage. The EtherDrive HBA is installed in the Windows host and presents the LUN as a locally attached SCSI disk. The HBA driver and EtherDrive HBA translate disk requests to AoE requests and transmit the requests to the EtherDrive SAN. As responses return from the EtherDrive SAN, the reverse translation occurs in the HBA driver.

To use Coraid's Ethernet SAN with your host, one or more Coraid EtherDrive HBAs must be installed. The EtherDrive HBA's two network ports are dedicated specifically for communication with Coraid Ethernet SAN appliances. At least one port from the EtherDrive HBA must be connected to the SAN where the Ethernet SAN is located.

## CorOS updates

You can copy a CorOS update file to an SR/SRX storage appliance using the HBA HostView tool that is installed along with the EtherDrive HBA driver (see [Copying the CorOS update file to an SR/SRX appliance](#)). The copied file must then be processed from the SR/SRX console to update the CorOS (as described in the *Coraid EtherDrive SR/SRX Administration Guide*).

## Coraid Ethernet Console (CEC)

The HBA HostView tool that is installed with the EtherDrive HBA driver includes the CEC (Coraid Ethernet Console) utility. CEC allows you to establish a console connection to SR/SRX appliances from the host using standard Ethernet frames. Once the host is connected to the SAN through CEC, you can issue commands as though you are connected to the SR/SRX console (see [Using CEC from HBA HostView](#)).

## Overview of Installation

To install your Coraid EtherDrive HBA for Windows Server:

- Configure the Coraid EtherDrive SAN. For instructions, see the *Coraid EtherDrive SR/SRX Administration Guide* and the *Coraid EtherDrive VSX Administration Guide*.
- Install the EtherDrive HBA card in your host. For instructions, see [Installing an EtherDrive HBA Card](#).
- Determine the version of any previously installed EtherDrive HBA driver on your host. Depending on the version, you may have to uninstall it. For instructions, see [To install the EtherDrive HBA driver and HBA HostView on your Windows host](#).
- Install the Coraid EtherDrive HBA driver and HBA HostView. For instructions, see [Installing the EtherDrive HBA Driver and HBA HostView](#).
- Complete your storage configuration.

## Requirements

- In order to manage storage with the EtherDrive HBA, one or more SR/SRX or VSX LUNs must be present and online on the Ethernet SAN.
- The Coraid EtherDrive HBA should only be used in conjunction with Coraid Ethernet SAN appliances (SR/SRX and VSX).
- The EtherDrive HBA requires an HBA driver. Install it as described in [Installing the EtherDrive HBA Driver and HBA HostView](#).
- Make sure the host is running one of the following supported Windows operating systems:
  - Microsoft Windows Server 2008 R2 64-bit (standard and Server Core installations)
  - Microsoft Windows Server 2003 R2, 32- and 64-bit
  - Microsoft Windows Server 2003, 32- and 64-bit
- Because the AoE protocol is not routable, the EtherDrive HBA and the EtherDrive SAN must be connected to the same network broadcast domain.
- The EtherDrive HBA requires an available PCI Express (PCIe®) slot in the host.
- SAN Ethernet ports—HBA cards are available in the following SAN port configurations. Use high-quality cables when connecting to these ports.
  - EtherDrive EHBA-2-E-RJ45-2 x 1GbE UTP
  - EtherDrive EHBA-20-E-RJ45-2 x 10GbE UTP
  - EtherDrive EHBA-20-E-CX4-2 x 10GbE CX4
  - EtherDrive EHBA-20-E-SFP-2 x 10GbE SFP+
- The EtherDrive HBA must be connected to a network switch that supports flow control (IEEE 802.3) and jumbo frames with an MTU size of 9000 or greater.

**Note:** It is recommend that you isolate the SAN from other network traffic in order to dedicate it exclusively for storage.

## Terminology

The information in this guide assumes familiarity with common data storage and networking concepts and familiarity with data center operations. Users unfamiliar with standard networking and storage terminology are encouraged to find definitions for unfamiliar terms using Web resources and reference documents.

This guide uses the following terms that might be unfamiliar to you or are specific to Coraid products.

Term	Definition
AoE	ATA-over-Ethernet protocol.
AoE Target	The shelf and LUN combination used to identify a block storage device on the Ethernet SAN.
Host	The computer accessing the storage over the Ethernet SAN.
CorOS	Operating system software that is embedded into—and distributed as an integral part of—the Coraid hardware storage solution.
EtherDrive SAN Manager (ESM)	ESM provides live monitoring and management of EtherDrive appliances that use the AoE protocol, such as the SR and SRX.
HBA (Host Bus Adapter)	An HBA connects a host computer to network storage. Coraid offers a range of HBAs with support for a variety of operating systems.  For more information see <a href="http://www.coraid.com">www.coraid.com</a> .
LUN (Logical Unit Number)	A grouping of uniquely numbered blocks of storage attached to a storage appliance by Ethernet SAN, in which each block contains 512 bytes of data. Each LUN contains one RAID or JBOD. An SR/SRX JBOD is a single-disk LUN.  The terms “LUN,” “target,” “AoE Target,” “device,” and “disk” are used interchangeably in this document.
Windows standard installation option	Standard GUI-based Windows Server 2008 environment.
Windows Server Core installation option	Windows Server 2008 installation option featuring a scaled-back Windows environment with no Windows Explorer shell. All configuration and maintenance is done through a command line interface. For instructions on using an EtherDrive HBA within a Server Core installation, see <a href="#">Managing Storage from a Command Line Interface</a> .

## Ethernet SAN Configuration

Before you can manage storage on the Ethernet SAN using your EtherDrive HBA, one or more SR/SRX or VSX LUNs must already exist and be online on the SAN. For instructions, see the *Coraid EtherDrive SR/SRX Administration Guide* and the *Coraid EtherDrive VSX Administration Guide*.

**Note:** RAID performance is suboptimal while a RAID on a LUN is initializing. For optimal performance, wait until RAIDs have finished initializing before using them.

## Installing an EtherDrive HBA Card

To use Coraid's Ethernet SAN with a Windows Server host, install one or more Coraid EtherDrive HBAs in the Windows host.

Seat the EtherDrive HBA(s) into an available PCIe slot with the host powered off. When the host is powered back on, each HBA port appears in Windows Device Manager as an unknown device.

After installing the EtherDrive HBA, install the EtherDrive HBA driver and HBA HostView software. For instructions, see [Installing the EtherDrive HBA Driver and HBA HostView](#).

### ***To install the EtherDrive HBA***

---

- 1. Follow ESD (electrostatic discharge) and other safety precautions when handling the EtherDrive HBA.**



Static discharge can destroy the circuits etched in silicon microchips or dramatically shorten their life span. To protect the EtherDrive HBA from damage, observe standard ESD precautions.

- 2. Power off the host and disconnect the power cable.**
- 3. Open the host chassis and locate an available PCIe slot.**
- 4. Remove the slot cover (if any) by removing the screw or releasing the lever.**
- 5. Seat the EtherDrive HBA firmly into the PCIe slot.**

To access an available slot, you might need to remove and replace existing PCIe cards or other hardware.

**6. Attach the EtherDrive HBA retaining bracket using the existing screw or lever.**

**Note:** Depending on whether you are using a full-height or half-height slot, you might need to change the retaining bracket on your EtherDrive HBA. Your EtherDrive HBA includes both a half-height and a full-height retaining bracket.

- (SFP+ EtherDrive HBA only) You must remove both transceivers before you can remove the retaining bracket.
- (CX4 EtherDrive HBA only) If you change the retaining bracket on your HBA, make sure you remove and replace the locking pin on each port carefully. Push on the pin one side at a time, alternating sides, until it comes loose or clicks back into place. The locking pin looks like this:



**7. Close the host chassis, and then connect the power cable(s).**

**8. Connect cables from the HBA SAN ports to an Ethernet switch connected to the SAN. The switch must support jumbo frames with an MTU size of 9000 (see **Requirements**).**

Each EtherDrive HBA provides two ports for communication with Coraid EtherDrive storage appliances. At least one port must be connected to the SAN network where the Ethernet SAN is located. You can also connect directly to the ports on the SR/SRX appliance.

**9. Power on the host.**

**10. Perform the procedure **Installing the EtherDrive HBA Driver and HBA HostView**.**

## Installing the EtherDrive HBA Driver and HBA HostView

After you install the EtherDrive HBA in the host, install the appropriate EtherDrive HBA driver and HBA HostView software (32-bit or 64-bit). The host will not recognize the EtherDrive HBA until the HBA driver software is installed. In these instructions, the version and release numbers in the file names are replaced by **xxx**. When you install the driver, substitute the actual name of the package you downloaded.

The EtherDrive HBA translates disk commands to and from AoE commands. The translation is transparent to the Windows host.

### ***To install the EtherDrive HBA driver and HBA HostView on your Windows host***

---

- 1. Download the latest Windows EtherDrive HBA driver installer package (32-bit or 64-bit) from:**

<http://www.coraid.com/support/downloads>

- 2. Uninstall any existing EtherDrive HBA driver, if necessary.**

If an EtherDrive HBA driver is already installed on the Windows host, you may have to uninstall it, depending on the version. To determine the version of the installed driver:

- Launch HBA HostView
- Click **Help > About**
  - If the driver is **v5.0.0** or later, do not uninstall it manually. Skip to **step 4**.
  - If the driver is earlier than **v5.0.0**, you must uninstall it manually as described in **step 3**.

- 3. To uninstall an EtherDrive HBA driver earlier than 5.0.0, do the following:**



This step is intended to ensure that no data is lost and that the Windows host does not crash when you uninstall a pre-v5.0.0 driver.

- Quiesce the applications running on the LUN(s) claimed by the Windows host.
- Flush cached data to disk using a utility such as Sync (available from Windows Sysinternals. Administrator privileges are required).
- Use the uninstall utility in Windows Control Panel to uninstall the Coraid EtherDrive HBA driver and HBA HostView tool.

- 4. Launch the driver installer package using the appropriate method:**

- **Microsoft Windows Server 2003 or 2008, standard installation:**

Double-click `etherdrive-hba-windows-x.x.x-Rx-xxbit.msi`

- **Microsoft Windows Server 2008, Server Core installation:**

– Log on to the host as Administrator. From the command line, change directories to the location of the installer package and type,


```
"msiexec /i <yourpath>\etherdrive-hba-windows-x.x.x-x1-xxbit.msi"
```

– Type the password when prompted.


5. Click Next in the Setup Wizard screen.




6. Review and accept the license agreement, then click Next.



**7. Specify where to install the software, then click Next.**



**8. Click Install to begin the installation.**



- 9. If notified that your Windows Server host does not already have the .NET Framework installed, install it. When you are finished, launch the EtherDrive-HBA file to resume installation.**
- 10. Click OK at the message "Please attach your device to this computer any time after the installation has finished."**
- 11. Click Finish.**
- 12. If prompted to do so, restart the host computer.**

After the Install Wizard is finished, the Windows host detects any connected AoE storage and the Ethernet SAN is available through Windows Disk Management.

## Managing Storage from HBA HostView

**Note:** HBA HostView is not supported in the **Windows Server Core** installation environment. To manage storage on your SAN from a command line interface (CLI) in either the standard Windows Server 2008 installation environment or the Windows Server 2008 Server Core installation environment, see [Managing Storage from a Command Line Interface](#).

HBA HostView allows you to:


- Claim and release LUNs (see [Claiming and releasing devices with HBA HostView](#)).
- View the status of HBA ports (see [Viewing the status of HBA ports with HBA HostView](#)).
- Establish a console connection to SR/SRX appliances through the CEC (Coraid Ethernet Console) utility (see [Using CEC from HBA HostView](#)).
- Gather debug information useful for working with Coraid Technical Support to resolve any issues (see [Viewing and capturing debug information with HBA HostView](#)).
- Copy a CorOS update file to an SR/SRX appliance. After you have copied the file to the SR/SRX, you can process it from the SR/SRX console to update the CorOS (see [Copying the CorOS update file to an SR/SRX appliance](#)).
- Access and use Windows Server Disk Management (see [Using Windows Disk Management with HBA HostView](#)).

## To start HBA HostView

- From the Windows Start menu, choose HBA HostView.

The appearance of the Start menu varies depending on the version of Windows you are using and the number of applications installed on your Windows host. If you do not see HBA HostView on the Start menu, navigate to **All Programs > Coraid > HBA HostView**.

The HBA HostView screen appears with the Devices tab displayed.



**Note:** If you do not see the LUN(s) you expect to see in the Devices tab, perform the actions detailed in [Frequently Asked Questions](#).

The Devices tab allows you to see and use available LUNs on your storage devices. The Devices tab also displays the mapping of LUNs-to-SCSI devices, the size of each device, and the HBA port through which each device is connected.

**Note:** LUN sizes are displayed in base 10 (consistent with the practice of hard drive manufacturers and storage vendors) in the Devices tab. Windows Server Disk Management reports disk sizes in base 2. As a result, the capacity displayed in the Device Size column of HBA HostView may differ from the capacity displayed in Windows Server Disk Management, but the actual capacity of the device is the same.

## Claiming and releasing devices with HBA HostView

Before you can use an AoE target (LUN) with your Windows host, you must claim it with HBA HostView. When viewed from HBA HostView running on your host, LUNs claimed by your host appear in the Devices tab with a SCSI ID.

**Note:** In a non-clustering environment, a claimed LUN can be used only by the host that claimed it. In a clustering environment, a claimed LUN can be used by more than one host (see [To claim an already-claimed LUN in a Windows clustering environment](#)).


### To claim a LUN (AoE Target)

1. Click the **Devices** tab.
2. Click **Refresh** to update the **AoE Targets** column.

Refresh clears from the Devices tab LUNs that have been removed and/or placed offline. For best results, wait a few minutes after removing or offlining a LUN before clicking Refresh to update the Devices tab.

3. Select the **LUN (AoE Target)** you want to claim.

Shift-click or Control-click to select multiple LUNs.




4. Click the **Claim** button.
5. If an initialization wizard launches, follow the on-screen prompts. For detailed instructions, see [Windows Help documentation](#).

### ***To claim an already-claimed LUN in a Windows clustering environment***

The Ethernet SAN and EtherDrive HBA support Windows Clustering technology (persistent reserve/release) which allows multiple hosts to share a single storage resource.

1. **Click the Devices tab.**
2. **Select the claimed LUN you want to share with the other claiming host.**
3. **Click the Claim button.**



**Note:** You cannot Shift-click or Control-click to select and claim multiple claimed LUNs simultaneously.

### ***To release a claim on a LUN held by the current host***

1. **In HBA HostView, click the Devices tab.**
2. **Click to select the LUN (AoE Target) you want to release.**  
Shift-click or control-click to select multiple LUNs.
3. **Click the Release button.**


### *To release a claim on a LUN held by another host*

1. Click the **Devices** tab.
2. Click to select the **LUN (AoE Target)** you want to release.

Shift-click or Control-click to select multiple LUNs.

3. Click the **Force Release** button.

Use Force Release with caution as it may cause data loss or corruption.




4. Click **Yes** in the warning message to verify that you want to release the device.

## Viewing the status of HBA ports with HBA HostView

The HBA Ports tab provides information about your ports.

### To view the status of HBA ports

#### 1. Click the HBA Ports tab.



For each port, the HBA Ports tab lists the port number, port type, MAC addresses, and current routing performance.

Your Coraid HBA features one of the following types of ports:

Port Type	Bus	Interface
EHBA-2-E-RJ45	1GbE PCIe	RJ45
EHBA-20-E-RJ45	10GbE PCIe	RJ45
EHBA-20-E-CX4	10GbE PCIe	CX4
EHBA-20-E-SFP	10GbE PCIe	SFP+

The Link State (Actual/Max) displays the current and maximum link speed for each port. If the speed is 0, the Ethernet cable may be missing, disconnected, or faulty, or the port may be down.

#### 2. Click Refresh to update the port information.

## Using CEC from HBA HostView

You can launch the CEC (Coraid Ethernet Console) utility from HBA HostView and establish a console connection to SR/SRX appliances. You can then issue commands from the host to SR/SRX appliances as though you are connected directly to the SR/SRX console. SR/SRX commands are detailed in the *Coraid EtherDrive SR/SRX Administration Guide*.


By factory default, current SR/SRXs provide the CEC connection through onboard RJ-45 ports ether0 and ether1. You can display and manage the SR/SRX CEC port configuration by issuing the commands `cecon` and `cecoeff`. CEC configuration persists across reboot.




CEC does not include any security or encryption mechanisms. Also, depending on your network configuration, be aware that enabling CEC and failing to logout may leave your system insecure. As with AoE, the appliance is only as secure as your network.

### To access CEC from HBA HostView

1. Click the Action menu and choose CEC Console.




2. In the Select Shelf box, click Refresh to update the list of SR/SRXs.



**3. Select a shelf and then click Open.**

Press Enter a few times until the prompt displays.




**4. To exit the CEC terminal, click the X in the upper left-hand corner of the window.**

## Viewing and capturing debug information with HBA HostView

The Debug tab displays debug information you can use or share with Coraid Support.

### To view and capture debug information

1. Click the Debug tab.



2. Click the Refresh button to display the most current information.
3. Click the Copy to Clipboard button to copy the complete contents of the Debug tab to your clipboard.
4. Paste the debug information into an email message to Coraid Support.

## Copying the CorOS update file to an SR/SRX appliance

CorOS (Coraid Operating System) is an integral part of the Coraid hardware storage solution. All Coraid Ethernet SAN appliances must use the latest CorOS version.

HBA HostView allows you to copy a CorOS update file to a pre-existing update LUN on an SR/SRX appliance. After the update file is staged to the update LUN, it must be processed from the SR/SRX console in order to update the CorOS on the appliance. For instructions, see the *Coraid EtherDrive SR/SRX Administration Guide*.

**Note:** Before updating the CorOS, you should restrict access to the storage appliance or quiesce the application(s) interacting with the appliance. To ensure that the update is completed without data loss, no writes should be performed to the appliance during the update.

### To copy the CorOS software update file to the SR/SRX update LUN

**1. Make sure there is an update LUN on the SR/SRX appliance.**


The update LUN must already exist on the SR/SRX appliance before you can copy the update file to it. (For a description of the update LUN, see [step 6](#) of this procedure. For instructions on creating the update LUN on an SR/SRX, see the *Coraid EtherDrive SR/SRX Administration Guide*.)

**2. Contact Coraid Technical Support for CorOS version information. Be prepared to provide the output of the `sos` command from your SR/SRX appliance.**


**3. Transfer the appropriate CorOS software update file to your Windows Server host.**

**4. Launch HBA HostView.**

**5. Click the Action menu and choose SRX CorOS Update.**



6. In the Update LUN column, click the box next to the update LUN(s) on which you want to install the CorOS update.



The update LUN(s) is a small (approximately 40MB) RAM-based LUN that is created from an ESM appliance (if present), or the SR/SRX console using the **make** command. When you choose SRX CorOS Update from the Action menu, the Coraid HBA HostView Tool looks for and then displays all LUNs on the SAN smaller than a certain size. Because there may be other small LUNs on your SAN in addition to the update LUN(s), make sure you know the shelf and LUN ID(s) of the update LUN(s) before you copy the update file to it. If you copy the update file to a wrong LUN, you may destroy data on that LUN.

7. Click **Browse**.
8. Navigate to the CorOS update file that you transferred in **step 3**, select the file, then click **Open**.
9. Click **Copy**.
10. After you are notified that the file was successfully copied to the SR/SRX LUN appliance(s), process the CorOS update file from the SR/SRX console.

For instructions, see the *Coraid EtherDrive SR/SRX Administration Guide*.

## Using Windows Disk Management with HBA HostView

Windows Disk Management allows you to view information (drive letter, label, size, type, and file system) about the volumes attached to your host. You can evaluate the information about the disk size and location to determine which disk shown in Windows Disk Management corresponds to an AoE LUN in HBA HostView.


After you have determined which disk corresponds to an AoE LUN, you can use Windows Disk Management to add descriptive text to the EtherDrive HBA volumes attached to your host. For instructions, see [To add descriptive text to an EtherDrive HBA volume](#).

For information about managing storage with Windows Disk Management, see the Windows Disk Management online help.


**Note:** In Windows Server 2008, shared storage is offline in the Disk Manager by default in order to prevent hosts from accessing storage that could be in use by another host. To change the status of a disk to Online or Offline, right-click the disk name and select the appropriate action.

### To view disk information in Windows Disk Management


1. From the Action menu of HBA HostView, choose Windows Disk Management.



- In the lower portion of the Disk Management window, right-click the box representing a disk that has been configured as a Coraid Volume, and then choose Properties.




- In the General tab, match the Location information to the SCSI ID shown in the Devices tab of HBA HostView.




### ***To add descriptive text to an EtherDrive HBA volume***

Consider adding the shelf.lun address of the Coraid-configured volume to the volume label (see [step 3](#) below). The volume label is visible in Windows Explorer and other places where disks are listed. Adding the shelf.lun address to a volume label makes it easy to see that a particular LUN displayed in Windows Disk Management is the same as a particular LUN displayed in HBA HostView

- 1. From the Action menu of HBA HostView, choose Windows Disk Management.**
- 2. In the upper portion of the Disk Management window, right-click the box representing a disk that has been configured as a Coraid Volume, and then choose Properties.**



- 3. Add descriptive text to the volume label and click Apply.**



4. When you have finished, click OK.

## Managing Storage from a Command Line Interface

This section describes the commands provided by the `ethdrvadm` command line interface utility bundled with the EtherDrive HBA driver. The `ethdrvadm` utility works with standard and Server Core Windows installation options (and is mandatory in Server Core installations).

**Note:** For details about the GUI-based HBA HostView tool that supports standard Microsoft Windows Server 2008 installations, see [Managing Storage from HBA HostView](#).

Before you can use the `ethdrvadm` utility to manage storage on the SAN, the following tasks must be completed:

- The EtherDrive Storage appliance is configured with at least one LUN.
- An EtherDrive HBA card(s) is installed in the host.
- The EtherDrive HBA is connected to a supported Ethernet switch or directly to an SR/SRX appliance.
- The current EtherDrive HBA driver is installed on the Windows host and the host has been rebooted (if a reboot is necessary; see [To install the EtherDrive HBA driver and HBA HostView on your Windows host](#)).

### Commands

The `ethdrvadm` utility provides the following commands:

```
ethdrvadm list
ethdrvadm list-devices
ethdrvadm list-ports
ethdrvadm claim
ethdrvadm release
ethdrvadm flush
ethdrvadm sos
```

Command usage includes the following conventions:

- `[/a]`—Displays more detailed information.
- `[/?]`— Displays usage information.
- `shelf.lun`— Use with `claim` and `release` to specify the particular LUN.
- `[/force]`— If necessary, append `/force` to `ethdrvadm release` to force the EtherDrive HBA to release a LUN.



**Note:** Data loss may result! The `/force` argument forces the host to release the LUN without first flushing cached data to disk.

## ■ ethdrvadm list

The `ethdrvadm list` command displays information about all the LUNs on the SAN that are visible to the EtherDrive HBA.

Usage: `ethdrvadm list [/a] [?]`

For example:

```
ethdrvadm list
```

DEVICE	TARGET	SIZE	PORTS	CLAIMING HOST
0:0:0	7.5	1000.204GB	0	Windows Host
0:0:1	7.6	900.165GB	0	Windows Host
-	20.5	900.165GB	0	GRAY
-	20.6	900.165GB	0	
-	20.7	900.165GB	0	
-	20.8	900.165GB	0	

Appending `/a` displays more detailed information.

For example:

```
ethdrvadm list /a
```

DEVICE	TARGET	SIZE/ PORT	PORTS/ ADDRESS	CLAIMING HOST
0:0:0	7.5	1000.204GB	0	Windows Host
		0	00304800000a	
0:0:1	7.6	900.165GB	0	Windows Host
		0	00304800000a	
-	20.5	900.165GB	0	GRAY
		0	00259008a811	
-	20.6	900.165GB	0	
		0	00259008a811	
-	20.7	900.165GB	0	
		0	00259008a811	
-	20.8	900.165GB	0	
		0	00259008a811	

### ■ ethdrvadm list-devices

The `ethdrvadm list-devices` command displays information about the LUNs claimed by the EtherDrive HBA installed in your Windows host.

Usage: `ethdrvadm list-devices [/a] [?]`

For example:

```
ethdrvadm list-devices
DEVICE      TARGET      SIZE          PORT
0:0:0       7.5         1000.204GB    0
0:0:1       7.6         900.165GB     0
```

Appending `/a` displays more detailed information.

For example:

```
ethdrvadm list-devices /a
DEVICE      TARGET/     SIZE/        PORT
            PORT       ADDRESS
0:0:0       7.5        1000.204GB   0
            0          0030480000a
0:0:1       7.6        900.165GB   0
            0          0030480000a
```

### ■ ethdrvadm list-ports

The `ethdrvadm list-ports` command displays information about attached ports.

Usage: `ethdrvadm list-ports [?]`

For example:

```
ethdrvadm list-ports
PORT  MODEL          ADDRESS          SPEED
0     EHBA-20-E-RJ45 0010040102e3    10000/10000
1     EHBA-20-E-RJ45 0010040102e2    10000/10000
```

The `SPEED` column displays the current and maximum link speed (in that order) for each port. If the speed is 0, the Ethernet cable may be missing, disconnected, or faulty, or the port may be down.

### ■ ethdrvadm claim

Issue `ethdrvadm claim` to claim a LUN.

Usage: `ethdrvadm claim shelf.lun`

For example:

```
ethdrvadm claim 7.5
Claim operation succeeded
```

### ■ ethdrvadm release

The `ethdrvadm release` command releases the EtherDrive HBA's claim to the specified LUN. A successful release operation unmounts the disk, flushes uncached data to disk, and then releases the LUN.

Usage: `ethdrvadm claim [/force] shelf.lun`

For example:

```
ethdrvadm release 7.5
Release operation succeeded
```

For example:

```
ethdrvadm release /force 7.5
Force release request sent
```

Appending `/force` forces the EtherDrive HBA to release the LUN.



**Note:** Data loss may result! The `/force` argument forces the host to release the LUN without first flushing cached data to disk.

### ■ ethdrvadm flush

The `ethdrvadm flush` command refreshes the output of `ethdrvadm list` and `ethdrvadm list-devices` command to remove targets that are no longer present on the SAN.

### ■ ethdrvadm sos

The `ethdrvadm sos` command displays diagnostic information that you can send to the Coraid Technical Assistance Center. For the quickest solution to your problem, include the `ethdrvadm sos` output with your initial contact to the Coraid Technical Assistance Center.

**Note:** The `ethdrvadm sos` command only displays information regarding configuration and status of this Windows host. It does not include any information about the data stored on the SAN.

## Frequently Asked Questions

**Question:** The Coraid EtherDrive HBA looks like a standard Network Interface Card (NIC). Can I use the Coraid EtherDrive HBA for IP traffic?

**Answer:** No. The Coraid EtherDrive HBA is a dedicated storage device. Dedication allows the EtherDrive HBA to process storage commands at an exceptionally fast rate.

**Question:** What do I have to configure to use Multipath?

**Answer:** Nothing! The Coraid EtherDrive HBA driver automatically handles Multipath for all of the available EtherDrive HBA ports. Even if a single host has two EtherDrive HBA cards, the EtherDrive HBA driver automatically uses the ports on both devices.

**Question:** I understand that I need a Coraid EtherDrive HBA for my host in order to utilize my Ethernet SAN appliances. Do I also need an EtherDrive HBA for each of my Ethernet SAN appliances?

**Answer:** No. Only one Coraid EtherDrive HBA is required for each host. One EtherDrive HBA can communicate with any EtherDrive SAN appliance running a compatible version of the CorOS. You can add additional EtherDrive HBAs to your host if you have unusual security or bandwidth requirements or if your storage exceeds the limitations of your operating system.

**Question:** Why don't I see the LUN(s) that I expect to see when I launch HBA HostView?

**Answer:** If the LUNs you expect to see do not appear in the Devices tab of HBA HostView, do the following:

- Make sure that one or more SR/SRX LUNs are present and online on the Ethernet SAN.
- Make sure you have clicked the **Refresh** button in HBA HostView, or issued the **ethdrvadm flush** command from a command line interface.
- Make sure that hibernation mode is disabled on the Windows host.
- Make sure the CorOS running on your EtherDrive SAN appliances is compatible with the version of the EtherDrive HBA driver installed in your host.
- Make sure that all cables are routed correctly throughout the SAN and only Cat 6 cables are used for AoE traffic.
- Make sure the switch (if any) to which your host is connected supports flow control (IEEE 802.3) and jumbo frames with an MTU (Maximum Transmission Unit) size of 9000 or greater and is configured to operate at the proper link speed.
- Make sure the Coraid EtherDrive HBA is correctly seated in a PCI Express (PCIe<sup>®</sup>) slot in the host.

## Coraid Policy Statements, Warranty and EULA

### Technical support

Do you have more questions? See the Coraid Support web site:

<http://www.coraid.com/support/>

Contact the Coraid Technical Assistance Center at:

[support@coraid.com](mailto:support@coraid.com)

To help the Technical Assistance Center diagnose your problem, send diagnostic output along with a description of your problem. To obtain diagnostic output, issue the **sos** command.

### Warranty and return policy



**CAUTION: If the product includes hard disk drives, do not ship the product with hard disk drives installed! Doing so may damage the product and void the warranty!**

Unless other Warranty provisions have been provided in a separate purchase contract, this Limited Warranty shall apply to all Coraid manufactured Products. Coraid Inc. (“Coraid”) provides this Limited warranty to the entity that originally purchased the new Coraid Product, from Coraid or its authorized reseller.

Coraid’s return policy is that all sales are final, with no refund or return provision, unless a prepaid 30-day money-back trial has been arranged prior to order shipment.

#### Limited hardware warranty

Coraid warrants that the Hardware portion of the Coraid Products described below will be free from material defects in workmanship and materials for the period of thirty six (36) months from the date of original purchase of the Product from Coraid or its authorized reseller (“Warranty Period”).

Disk drives supplied by Coraid as marked and Certified disk drives may be returned to Coraid for repair or replacement during the Warranty Period. If the hard disk drives or solid state drives (SSDs) are properly used and installed in Coraid products, they will be free from defects in material and workmanship, and will substantially conform to the disk manufacturer’s publicly available specifications for a period of three (3) years beginning on the date the Product was purchased. Coraid Products and Coraid Certified disks or SSDs used outside their published specifications, are not covered under this warranty.

Coraid’s sole obligation shall be to repair or replace the defective Hardware during the Warranty Period at no charge to the original owner or to refund at Coraid’s sole discretion. Such repair or replacement will be rendered by Coraid at Coraid’s Service Center. The replacement Hardware need not be new nor have an identical make, model or part. Coraid may in its sole discretion replace the defective Hardware (or any part thereof) with any reconditioned product that Coraid reasonably determines is substantially equivalent (or superior) in all material respects to the defective Hardware. Repaired or replacement Hardware will be warranted for the remainder of the original Warranty Period from the date of original Product purchase from Coraid or its authorized reseller.

### **Submitting a claim**

The customer shall obtain a Return Material Authorization (“RMA”) number from Coraid service center and return the Product to Coraid. The customer must submit with the Product as part of the claim a written description of the hardware defect or Software nonconformance in sufficient detail to allow Coraid to confirm the same.

After an RMA number has been issued by Coraid, the defective Product must be packaged securely in suitable shipping package to ensure that it will not be damaged in transit, and the RMA number must be prominently marked on the outside of the package. The customer is responsible for all return shipping charges to Coraid, and Coraid will not be held responsible for any packages that are lost in transit to Coraid.

Return Product ship to address is: Coraid Inc. 2393 Pendley Rd, Suite 200, Cumming, Georgia 30041

### **What is not covered**

This limited warranty provided by Coraid does not cover repair of Products, if in Coraid’s judgment, Product has been subjected to abuse, accident, alteration, modification, tampering, negligence, misuse, faulty installation, lack of reasonable care, repair or service in any way that is not contemplated in the documentation for the product. Damage that occurs in shipment, due to act of God, failures due to power surge, and cosmetic damage is not covered. Any hardware, software, firmware or other products or services provided by anyone other than Coraid is not covered. Loss of stored data for any reason is not covered under this Limited Warranty.

### **Disclaimer of other warranties**

EXCEPT FOR THE LIMITED WARRANTY SPECIFIED HEREIN, THE PRODUCT IS PROVIDED “AS-IS” WITHOUT ANY WARRANTY OF ANY KIND WHATSOEVER INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. IF ANY IMPLIED WARRANTY CANNOT BE DISCLAIMED IN ANY TERRITORY WHERE A PRODUCT IS SOLD, THE DURATION OF SUCH IMPLIED WARRANTY SHALL BE LIMITED TO NINETY (90) DAYS. EXCEPT AS EXPRESSLY COVERED UNDER THE LIMITED WARRANTY PROVIDED HEREIN, THE ENTIRE RISK AS TO THE QUALITY, SELECTION AND PERFORMANCE OF THE PRODUCT IS WITH THE PURCHASER OF THE PRODUCT.

### **Limitation of liability**

TO THE MAXIMUM EXTENT PERMITTED BY LAW, CORAID IS NOT LIABLE UNDER ANY CONTRACT, NEGLIGENCE, STRICT LIABILITY OR OTHER LEGAL OR EQUITABLE THEORY FOR ANY LOSS OF USE OF THE PRODUCT, INCONVENIENCE OR DAMAGES OF ANY CHARACTER, WHETHER DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF GOODWILL, LOSS OF REVENUE OR PROFIT, WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION, FAILURE OF OTHER EQUIPMENT OR COMPUTER PROGRAMS TO WHICH CORAID’S PRODUCT IS CONNECTED, LOSS OF INFORMATION OR DATA CONTAINED IN, STORED ON, OR INTEGRATED WITH ANY PRODUCT RETURNED TO CORAID FOR WARRANTY SERVICE) RESULTING FROM THE USE OF THE PRODUCT, RELATING TO WARRANTY SERVICE, OR ARISING OUT OF ANY BREACH OF THIS LIMITED WARRANTY, EVEN IF CORAID HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE SOLE REMEDY FOR A BREACH OF THE FOREGOING LIMITED WARRANTY IS REPAIR, REPLACEMENT OR REFUND OF THE DEFECTIVE OR NON-CONFORMING PRODUCT. THE MAXIMUM LIABILITY OF CORAID UNDER THIS WARRANTY IS LIMITED TO THE PURCHASE PRICE OF THE PRODUCT COVERED BY THE WARRANTY. THE FOREGOING EXPRESS WRITTEN WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ANY OTHER WARRANTIES OR REMEDIES, EXPRESS, IMPLIED OR STATUTORY.

### Governing law

This Limited Warranty shall be governed by the laws of the State of Georgia. Some states do not allow exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the foregoing limitations and exclusions may not apply. This limited warranty provides specific legal rights and the product owner may also have other rights which vary from state to state.

## Coraid End User License Agreement (EULA)

NOTICE: THIS PRODUCT CONTAINS COMPUTER PROGRAMS AND RELATED DOCUMENTATION (“SOFTWARE”) THAT BELONG TO CORAIID, INC., (“CORAIID”). BY DOWNLOADING AND INSTALLING, COPYING OR OTHERWISE USING THE SOFTWARE, LICENSEE AGREES TO BE BOUND BY THE TERMS OF THIS CORAIID MASTER END USER LICENSE AGREEMENT (“EULA”). IF YOU DO NOT AGREE TO THE TERMS OF THIS EULA, YOU MAY NOT DOWNLOAD, INSTALL, COPY OR USE THE SOFTWARE, AND YOU MAY RETURN THE UNUSED SOFTWARE TO THE VENDOR FROM WHICH YOU ACQUIRED IT WITHIN THIRTY (30) DAYS. WRITTEN APPROVAL IS NOT A PREREQUISITE TO THE VALIDITY OR ENFORCEABILITY OF THIS AGREEMENT.

### Definitions

“**Documentation**” means any end user manuals or documentation, and on-line help files regarding the use of each Software product that are generally provided by Coraid in connection with each Software product, as may be revised by Coraid from time to time.

“**Licensee**” means the natural person or business entity that is agreeing to be bound by this EULA, including (but not limited to) Licensee's employees, and any third party agents/contractors that provide services to Licensee. Licensee shall be liable for any failure by their employees and third party agents/contractors to comply with the terms of this EULA.

“**CorOS**” means the firmware operating system software that is embedded into, and distributed as an integral part of the Coraid hardware storage solution.

“**Host Bus Adaptor (HBA) Driver**” means the specific software adaptors allowing the CorOS firmware operating system to interoperate with the HBA network interface card (NIC) in the Coraid hardware storage solution.

“**Software**” means Coraid software products that are licensed to Licensee under this EULA, including, but not limited to the CorOS, the HBA Drivers, the User Interface, any related components purchased or provided with the Software, application programming interfaces, associated media, printed materials, online or electronic Documentation, and any updates and maintenance releases thereto.

“**User Interface**” means the software interface allowing a user to monitor, provision, and manage the individual HBAs, and the overall Coraid hardware storage solution.

### Grant and use rights for software

**License.** Subject to the terms and conditions of this EULA, Coraid grants Licensee a limited, non-exclusive, non-transferable, non-sublicensable, license to download, install, and/or use the Software (in object code form only), with authorized Coraid hardware products obtained by the Licensee from authorized Coraid distributors or resellers only. No rights or licenses in the Software are granted to Licensee other than those rights expressly granted in this Agreement. If the Software is a version that Licensee has converted or exchanged from a valid licensed prior version, Licensee agrees that by using the Software it will no longer use the prior version. Coraid reserves the right to require the certification of the destruction of such previous version of the Software. For the avoidance of doubt, the parties acknowledge and agree that the Software is licensed to Licensee by Coraid, and not sold.

**License Limitations.** Licensee may only install and use the Software in accordance with the documentation provided for the Software with Coraid hardware products purchased from a Coraid authorized source. Licensee may not copy the Software except for a reasonable number of machine-readable copies of the Software for backup or archival purposes and except as expressly permitted in this EULA. Licensee may not remove any titles, trademarks or trade names, copyright notices, legends, or other proprietary markings on the Software. Licensee is not granted any rights to any trademarks or service marks of Coraid. Coraid retains all rights not expressly granted to Licensee in this EULA.

**Restrictions.** Licensee shall not (and shall not allow any third party to) (i) decompile, disassemble, or otherwise reverse engineer or attempt to reconstruct or discover any source code, or underlying ideas or algorithms of the Software (except to the extent expressly permitted under applicable law); (ii) provide, lease, lend, use for timesharing or otherwise use or allow others to use the Software to or for the benefit of third parties; (iii) except as specified in the applicable user documentation, modify, incorporate into or with other hardware or software, or create a derivative work of any part of the Software; (iv) disseminate performance information or analysis from any source relating to the Software; (v) make any copies of the Software except as required to use the Software as licensed hereunder, except for one (1) copy solely for archival and back-up purposes, or (vi) remove any product identification, copyright notice or other proprietary legend from the Software. Licensee agrees to cooperate with Coraid and its licensors in connection with their efforts to protect their copyright/patent rights and other legal rights in the Software. Coraid may, from time to time, implement additional security measures for the Software, and Licensee shall cooperate with such measures and be responsible for installing upgrades that include such measures.

**Ownership and Title.** Notwithstanding anything to the contrary, Coraid and its licensors retains all right, title, and interest in and to the Software, all copies and derivative works thereof (by whomever produced), and in all related copyrights, trade secrets, patents, trademarks, and any other intellectual and industrial property and proprietary rights, including registrations, applications, renewals, and extensions of such rights anywhere in the world. The Software is only licensed to Licensee and is not sold.

**Confidentiality.** Licensee acknowledges that the Software contains valuable trade secrets of Coraid and other information proprietary to Coraid and its licensors. Licensee shall: (i) keep confidential such trade secrets and proprietary information, including without limitation all information concerning ideas and algorithms related to the Software, (ii) disclose such information only to its employees and agents to the extent required to use the Software under the terms of this Agreement and (iii) bind its employees, consultants, agents and other third parties in writing to maintain the confidentiality of such trade secrets and proprietary information and not use or disclose such information except as permitted in this Agreement.

### **Support and subscription services not included**

Coraid will not provide any support services for the Software under this EULA. This EULA does not give Licensee any rights to any updates or upgrades to the Software or to any extensions or enhancements to the Software developed by Coraid at any time in the future. Coraid or its partners may offer maintenance and support and services separately. If Licensee has purchased such maintenance and support and services with the Software, these services are provided to Licensee under the terms and conditions associated with such maintenance and support and services posted on Coraid's Web site at <http://www.coraid.com/support/> and by accepting the terms of this EULA Licensee is accepting these support terms and conditions. Any supplemental software code or related materials that Coraid provides to Licensee as part of any maintenance and support services are to be considered part of the Software and are subject to the terms and conditions of this EULA. Coraid may use any technical information Licensee provides to Coraid for any Coraid business purposes without restriction, including for product support and development. Coraid will not use information in a form that personally identifies Licensee.

### Term and termination

**Term.** This Agreement will become effective on the date Licensee clicks on the “I Accept” button or otherwise installs or uses the Software and will remain in force until terminated.

**Termination.** Coraid may terminate this EULA immediately and without notice if Licensee fails to comply with any term of this EULA.

**Effect of Termination.** In the event of termination, Licensee must destroy all copies of the Software. In addition Licensee must remove all copies of the Software, including all backup copies, from any server and all computers and terminals on which it is installed. From time-to-time, Coraid may change the terms of this EULA. Coraid will notify Licensee of such change. Licensee's continued use of the Software will indicate its agreement to the change.

### No warranty and limitation of liability

**NO WARRANTY.** THE SOFTWARE IS PROVIDED “AS IS” WITHOUT ANY WARRANTY OF ANY KIND INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. CORAID DOES NOT WARRANT THAT THE SOFTWARE IS ERROR-FREE OR THAT IT WILL OPERATE WITHOUT INTERRUPTION. CORAID DOES NOT WARRANT, GUARANTEE OR MAKE ANY REPRESENTATION REGARDING THE USE, OR THE RESULTS OF THE USE OF THE SOFTWARE INCLUDING, WITHOUT LIMITATION, THE CORRECTNESS, ACCURACY OR RELIABILITY OF SUCH USE OR RESULTS.

**LIMITATION OF LIABILITY.** TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE MANDATORY LAW, IN NO EVENT WILL CORAID AND ITS LICENSORS BE LIABLE FOR ANY LOST PROFITS OR BUSINESS OPPORTUNITIES, LOSS OF USE, BUSINESS INTERRUPTION, LOSS OF DATA, OR ANY OTHER INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES UNDER ANY THEORY OF LIABILITY, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, PRODUCT LIABILITY, OR OTHERWISE. BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE PRECEDING LIMITATION MAY NOT APPLY TO LICENSEE. CORAID AND ITS LICENSORS' LIABILITY UNDER THIS EULA WILL NOT, IN ANY EVENT, EXCEED THE LICENSE FEES, IF ANY, PAID BY LICENSEE FOR THE SOFTWARE LICENSED TO LICENSEE UNDER THIS EULA. THE FOREGOING LIMITATIONS SHALL APPLY TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, REGARDLESS OF WHETHER CORAID OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND REGARDLESS OF WHETHER ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

### General

**Entire Agreement.** This Agreement sets forth Coraid's entire liability and Licensee's exclusive remedy with respect to the Software and supersedes the terms of any purchase orders and any other communications or advertising with respect to the Software. You acknowledge that this Agreement is a complete statement of the agreement between you and Coraid with respect to the Software, and that there are no other prior or contemporaneous understandings, promises, representations, or descriptions with respect to the Software.

**Headings.** Headings under this EULA are intended only for convenience and shall not affect the interpretation of this EULA.

**Waiver and Modification.** No failure of either party to exercise or enforce any of its rights under this EULA will act as a waiver of those rights. This EULA may only be modified, or any rights under it waived, by a written document executed by the party against which it is asserted. NO VENDOR, DISTRIBUTOR, DEALER, RETAILER, SALES PERSON OR OTHER PERSON IS AUTHORIZED TO MODIFY THIS AGREEMENT OR TO MAKE ANY WARRANTY, REPRESENTATION OR PROMISE WHICH IS DIFFERENT THAN, OR IN ADDITION TO, THE REPRESENTATIONS OR PROMISES IN THIS AGREEMENT.

**Severability.** If any provision of this EULA is found illegal or unenforceable, it will be enforced to the maximum extent permissible, and the legality and enforceability of the other provisions of this EULA will not be affected.

**Governing Law.** This EULA will be governed by California law and the United States of America, without regard to its choice of law principles. The United Nations Convention for the International Sale of Goods shall not apply.

**Language.** This Agreement is in the English language only, which language shall be controlling and any revision of this Agreement in any other language shall be non-binding.

**Government Restrictions.** You may not export or re-export the Software except in compliance with the United States Export Administration Act and the related rules and regulations and similar non-U.S. government restrictions, if applicable. The Software and accompanying documentation are deemed to be “commercial computer software” and “commercial computer software documentation,” respectively, pursuant to DFAR Section 227.7202 and FAR Section 12.212(b), as applicable. Any use, modification, reproduction, release, performing, displaying, or disclosing of the Software by the U.S. Government shall be governed solely by the terms of this EULA.

**Contact Information.** If you have any questions about this EULA, or if you want to contact Coraid for any reason, please direct all correspondence to: Coraid, Inc., 255 Shoreline Drive, Suite #650, Redwood City, CA 94065 United States of America or email [info@Coraid.com](mailto:info@Coraid.com).

**Other.** Coraid, CorOS, EtherDrive, and RAIDShield are trademarks and/or registered trademarks of Coraid, Inc. in the United States and/or various jurisdictions.

**SOFTWARE PRODUCT SPECIFIC TERMS AND CONDITIONS.** In addition to the above, the Software products shall also be subject to any product-specific additional terms and conditions that accompany the specific Coraid Software product. In the event of any conflict between the product-specific terms and conditions and the preceding sections, the product-specific terms and conditions shall control with respect to the specific Coraid Software product.

## Additional Safety Information

**WARNING:** Read the installation instructions before connecting the system to the power source.

**ATTENTION:** Avant de brancher le système sur la source d'alimentation, consulter les directives d'installation.

**WARNUNG:** Vor dem Anschließen des Systems an die Stromquelle die Installationsanweisungen lesen.



### Lithium battery notice for service personnel

This product contains a lithium battery. Although the battery is not field-serviceable, observe the following warning:

**CAUTION:** Danger of explosion if battery is replaced with incorrect type. Replace only with the same type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

**ATTENTION:** Il y a danger d'explosion s'il a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du meme type ou d'un type equivalent recommande par le constructeur. Mettre au rebut les batteries usages conformement aux instructions du fabricant.

**WARNUNG:** Bei Einsetzen einer falschen Batterie besteht Explosionsgefahr. Ersetzen Sie die Batterie nur durch den gleichen oder vom Hersteller empfohlenen Batterietyp. Entsorgen Sie die benutzten Batterien nach den Anweisungen des Herstellers.



### Dual power supply notice

**WARNING:** This unit has more than one power supply connection; all connections must be removed to remove all power from the unit.

**WARNUNG:** Diese Einheit verfügt über mehr als einen Stromanschluß; um Strom gänzlich von der Einheit fernzuhalten, müssen alle Stromzufuhren abgetrennt sein.

**ATTENTION:** Cette unité est équipée de plusieurs raccordements d'alimentation. Pour supprimer tout courant électrique de l'unité, tous les cordons d'alimentation doivent être débranchés.



**WARNING:** This product relies on the building's installation for shortcircuit (over current) protection. Ensure that a fuse or circuit breaker no larger than 120 VAC, 15 A U.S. (240 VAC, 10 A international) is used on the phase conductors (all current carrying conductors).

**ATTENTION:** Pour ce qui est de la protection contre les courts-circuits (surtension), ce produit dépend de l'installation électrique du local. Vérifier qu'un fusible ou qu'un disjoncteur de 120 V alt., 15 A U.S. maximum (240 V alt., 10 A international) est utilisé sur les conducteurs de phase (conducteurs de charge).

**WARNUNG:** Dieses Produkt ist darauf angewiesen, daß im Gebäude ein Kurzschluß- bzw. Überstromschutz installiert ist. Stellen Sie sicher, daß eine Sicherung oder ein Unterbrecher von nicht mehr als 240 V Wechselstrom, 10 A (bzw. in den USA 120 V Wechselstrom, 15 A) an den Phasenleitern (allen stromführenden Leitern) verwendet wird.



### Laser warning

**WARNING:** Class 1 Laser product.

**ATTENTION:** Produit laser de classe 1

**WARNUNG:** Laserprodukt der Klasse 1

EtherDrive equipment is intended for installation in restricted access areas.



## Mounting the unit

**WARNING:** To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. These guidelines are provided to ensure your safety:

- This unit should be mounted at the bottom of the rack if it is the only unit in the rack.
- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.

**ATTENTION:** Pour éviter toute blessure corporelle pendant les opérations de montage ou de réparation de cette unité en casier, il convient de prendre des précautions spéciales afin de maintenir la stabilité du système. Les directives ci-dessous sont destinées à assurer la protection du personnel.

- Si cette unité constitue la seule unité montée en casier, elle doit être placée dans le bas.
- Si cette unité est montée dans un casier partiellement rempli, charger le casier de bas en haut en plaçant l'élément le plus lourd dans le bas.
- Si le casier est équipé de dispositifs stabilisateurs, installer les stabilisateurs avant de monter ou de réparer l'unité en casier.

**WARNUNG:** Zur Vermeidung von Körperverletzung beim Anbringen oder Warten dieser Einheit in einem Gestell müssen Sie besondere Vorkehrungen treffen, um sicherzustellen, daß das System stabil bleibt. Die folgenden Richtlinien sollen zur Gewährleistung Ihrer Sicherheit dienen:

- Wenn diese Einheit die einzige im Gestell ist, sollte sie unten im Gestell angebracht werden.
- Bei Anbringung dieser Einheit in einem zum Teil gefüllten Gestell ist das Gestell von unten nach oben zu laden, wobei das schwerste Bauteil unten im Gestell anzubringen ist.
- Wird das Gestell mit Stabilisierungszubehör geliefert, sind zuerst die Stabilisatoren zu installieren, bevor Sie die Einheit im Gestell anbringen oder sie warten.

## Regulatory certifications

### United States FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Canada compliance statement (Industry Canada)

This Class [A] digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe [A] respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

## Safety standards

- UL 60950-1: 2007
- CAN/CSA C22.2 No. 60950-1-07
- EN60950-1: 2006 +A11: 2009
- Emissions Standards: FCC Part 15B Class A
- EN 55022: 2006 plus A1:2007
- EN 61000-3-2: 2006
- EN 61000-3-3: 2008
- EN 55024: 1998 plus A1:2001 & A2:2003
- Australian/New Zealand Standard AS/NZS CISPR 22: 2009

## European Union (CE) Statement

This product is in conformity with the essential requirements of the following EU directives:

- 2004/108/EC--- Electromagnetic Compatibility Directive (EMC)
- 2006/95/EC---- Low Voltage Directive (LVD)